ASUS PAD
Screen Saver SOP

Version: 1.x.x
Model: ASUS MEMO Pad ME301T
Language: Multi-Language

/ISUS® Inspiring Innovation·Persistent Perfection

Step1 – Download Screensaver files

1. Download ME301 Screensaver file from "ASUS DEMO Program Resource Site"

Link: http://www.asus.com/microsite/demo/MeMO_Pad_Smart.htm

Step1 – Download Screensaver files

2. *Unzip ME301_Screensaver_0503.zip to ME301 internal storage

*Choose [Extract Here] to unzip ME301_Screensaver_0503.zip file and copy [Screensaver] folder to ME301 internal storage

Step2 – Enable Screen Saver

Settings→ ASUS customized setting →Enable the Screen Saver

Step3 – Select Screensaver Display Type

- Settings→ ASUS customized setting →Screen Saver settings

- Check [Enable the Screen Saver] & [Quick Launch]

- Display type select "Video"

- Select the video file location: /storage/sdcard0/Screensaver/301.mp4

Step4 – Screen Saver settings

- General Settings

- Enable the Screen Saver

Launch Screen Saver when the screen times out

(Time out =The device goes into sleep mode and it based on the setting of Sleep)

Step5 – Screen Saver settings

- General Settings

- If you enable "Launch with AC adapter"
  Need to plug the charger when the screensaver is playing to ensure
  ample power for your device.

Step6 – Screen Saver settings

- General Settings

- If you enable "Quick Launch "

    Launch Screensaver display by pressing power key

Step7 – Screen Saver settings

- Display Settings

  You can set Screen Saver duration (30 minutes,1 hour..)

THANK YOU

/ISUS® Inspiring Innovation · Persistent Perfection